



ALADDIN

Assembly instruction

1/8




+	3a	+	3	+	3b	2 x 40	88
---	----	---	---	---	----	--------	----

ALADDIN

Assembly instruction

2/8




4	+	5	+	5	+	6	4 x 70	12
4	5	5	6	+	base		4 x 60	16

ALADDIN

Assembly instruction

3/8



+

8

4 x 70

10



+

7



4 x 60

6

ALADDIN

Assembly instruction

4/8





+ **21**

3,5 x 50	2
20 x 20 x 40	4
3,5 x 25	16

ALADDIN

Assembly instruction

5/8





+	10a	+	10	+	10b	2,5 x 50	54
---	-----	---	----	---	-----	----------	----

ALADDIN

Assembly instruction


6/8



+

20

4,5 x 80	4
40 x 40 x 20	4
3,5 x 25	16



+

11

+


12

3,5 x 40	12
3,5 x 40	2

ALADDIN

Assembly instruction

7/8




+

13

3,5 x 40

12



+

ROOFING


1,5 x 16

84

ALADDIN

Assembly instruction

8/8



+

24

3,5 x 30

12

+

16

3,5 x 16

8